HARMSCO[®]

All-Poly High Purity



Hydrophobic Membrane

Pleated Teflon[®] Membrane Cartridges

Harmsco[®] High Purity Pleated Cartridges are manufactured for use in most applications where absolute rated filtration is needed.


Long service life High flow rates Low pressure drop High permeability

Features

- High efficiency for critical filtration applications
- Pleated design for extended surface area
- Polypropylene end cap, thermally welded to media, cage and core
- FDA Listed Materials for potable water/liquid foods
- USP Class VI 121°C (250°F) for plastics
- 8.5 square feet of filtration media per 9-3/4" cartridge
- Offered in multiple lengths and end cap configurations to fit in competitive filter housings

Applications

- Sterile Air
- Venting
- Photographic Solutions
- Reagent and Electronic Grade Chemicals
- Prefiltration Prior To Membrane Filters
- DI and RO Feedwater Prefiltration



Pleated Teflon[®] Membrane Cartridges

- Agressive Fluids
- Process Water
- Fine Chemicals
- Plating Chemicals
- Wastewater
- Pharmaceuticals and Biologicals



HARMSCO[®] Filtration Products

Teflon[®] Membrane Cartridges

Specifications


Construction Materials	Media Surface Area
Filtration MediaTeflon® Membrane	8.5 square feet per 9-3/4" length
Support MediaPolypropylene	
End Caps Polypropylene	Max. Recommended Operating Conditions
Center CorePolypropylene	Change OutΔP 35 PSI; Temperature200°F (93°C)
Outer Support CagePolypropylene O-rings/GasketsBuna, Viton, EPDM,	FDA Listed Materials
Silicone, Teflon [®] Encapsulated Viton	Manufactured from materials which are listed for food contact applications in Title 21 of the U.S. Code of Federal Regulations.
Dimensions	
Length: 10 to 40 inches (25.4 to 101.6 cm) nominal	Sanitization/Sterilization
Outside Diameter: 2.7 inches (7.0 cm) nominal	Filtered Hot Water 176°F (80°C) for 30 minutes
Toxicity	Steam Sterilization
All polypropylene components meet the specifications for biological safety per USP Class VI: 250°F (121°C) for plastics.	Chemicals: cartridges are chemically compatible with most chemicals and sanitizing agents.
	Note: stainless steel insert option needed for all cartridges being hot water sanitized or steam sterilized.

Cartridge Selection/Sizing Guide

								Pa	Packed 6 per case, with cartridges individually bagged and cartoned			
~	Model	~	Length	r	Micron Size	~	End Cap Code	~	O-Rings/Gaskets	~	Adders	
	TF		975 (9-3/4")		0.1		DOE (double open end)		E (EPDM)*		I (stainless steel insert)	
			195 (19-1/2")		0.2		213 (internal o-ring)		B (Buna)		HP (heavy poly core)	
			20 (20")		0.45		222 (flat cap)		S (Silicone)			
			2925 (29-1/4")				222-F (fin)		V (Viton)			
			30 (30")				222-S (spring)		T (Teflon Encapsulated Viton)			
			40 (40")				226 (flat cap)					
							226-F (fin)					
							226-S (spring)					

Example: TF – 195 – 0.45 – 222-F – E

Flow Rate



Cartridge End Cap Configurations

Flat Cap





*EPDM is standard for all o-rings and gaskets, unless otherwise noted.

Fin

226 (w/SS insert)

226

222 (w/SS insert)





Spring

222

9

Flat Cap

DOE (double open end)

Note: This publication is to be used as a guide. The data within has been obtained from many sources and is considered to be accurate. Harmsco does not assume liability for the accuracy and/or completeness of this data. Changes to the data can be made without notification. Temperature, Pressure, Flow Rates, Differential Pressures, Chemical Combinations and other unknown factors can affect performance in unknown ways. Limited Warranty: Harmsco warrants their products to be free of material and workmanship defects. Determination of suitability of Harmsco products for uses and applications contemplated by Buyer shall be the sole responsibility of Buyer. The end user/installer/buyer shall be liable for the product's performance and suitability regarding their specific intended applications. End users should perform their own tests to determine suitability for each application.

HARMSCO[®] Filtration Products

www.harmsco.com



7169 49th Terrace North, Riviera Beach, FL 33407 (561) 848-9628 • Toll-free: (800) 327-3248 • Fax: (561) 845-2474 • E-mail: sales@harmsco.com

© Harmsco, Inc.

^{12/17}